

Part List Per Kit

Part	Part #	Description	Qty.
A	11-80HHDD	0.5" Phenolic Cover Panel (HHDD=Height and Depth)	1
B	40-8261850	Traditional Plus SS Shoulder Bolt and Barrel Nut Set	6

Recommended Tools: T27 Pin Torx bit, Drill, Clamps

Once lockers are installed, a cover panel can be added to the exterior of the last locker in the run to provide a finished look.

- Align the front face and top of the locker with the front and top edge of the cover panel (it is optional to clamp the locker and end panel together to prevent movement)
- Place the barrel nut in the pre drilled (C) banking hole from the interior of the locker and thread the bolt into it from the exterior of the cover panel at the same predrilled location. Ensure alignment of the front and top edges then tighten the bolts.

