

**Part List Per Kit**

Part	Part #	Description	Qty.
A	40-8261840	Traditional SS Shoulder Bolt and Barrel Nut Set	6
B	40-8261850	Traditional Plus SS Shoulder Bolt and Barrel Nut Set	6

**Recommended Tools:** T27 Pin Torx bit, Drill, Clamps

During the locker installation process, banking bolts are used to attach individual lockers to one another. The banking bolts received (either Part A or B) will be determined based on whether ordering Traditional (A) or Traditional Plus (B) Lockers

- Align the front face and top of the lockers (it is recommended to clamp lockers together to prevent movement)
- Place the barrel nut in the pre drilled (C) banking hole from the interior of one locker and thread the bolt into it from the interior of the adjacent locker at the same predrilled location. They should be tightened slightly, at first. Once the lockers are flush and ready to be fastened to the wall, fully tighten the barrel nut and bolt.

