

Part List Per Kit

Part	Part #	Description	Qty.
A	11-972XXFT-XXXX	Polymer Flat Top XX" x 72"	1
B	40-3264320	Screw #14 x 3/4"	8

Recommended Tools: T27 Torx bit, Drill and Ø 3/16" drill bit, Clamps

Flat Tops can be added to the top for a finished look. Flat tops are 1/2" polymer and come in 72" lengths. The depth of the panel matches the depth of the locker.

- Locate flat top, place on top of locker (chamfered edges face up).
- Line up the flat top panel with the front face of the locker.
- Pre-drill holes using a Ø 3/16" drill bit from the interior of the locker. Drill through the locker top (may be 3/8" or 1/2") into the underside of the flat top. **Do not drill through the flat top.**
- Fasten the flat top to the locker using the screws provided (B) from the interior of the locker
- The last flat top will be cut to length to finish the run. The cut edge should be turned to the interior of the run to prevent exposing the sharp edge.
- Use the above methods when installing over fillers and blocking to secure flat top panel.

